

1. TPMS Self-Check Guide

Step 1: Measure Tire Pressure

Use a tire gauge to check each tire's air pressure, including the spare. Compare readings with the recommended pressure found on the driver's side door sticker or in your vehicle manual.

Step 2: Inspect for Visible Damage

Look for signs of wear, like cracks or bulges. Low-pressure tires are more prone to damage and blowouts.

Step 3: Reset TPMS Light (if needed)

Follow your car's manual to reset the TPMS light, which may require pressing a specific reset button or driving at a steady speed for a few minutes.

Step 4: Professional Calibration

If the light persists, it could indicate a sensor issue. Visit a professional to recalibrate or replace the sensor.